


User manual

9353003209/9353003201

Axessline Micro

1 USB-C & 1 USB-A charger 12W

Powerdot MICRO with 1 USB Type A charging connector and 1 USB Type C charging connector




x1

Powerdot MICRO fastening nut




x1

USB Type A Power adapter 9V-12-V, 1.5A




x1

USB Type A to USB Type C cable, 1450 mm




x1


- 1 DRILL**
Drill a hole in the table/furniture.



- 2 INSERT**
Insert the Powerdot MICRO into the hole, then feed the power cable through the plastic fastening nut.



- 3 USE FASTENING NUT**
Turn the fastening nut s far up the thread as possible by turning clockwise until the product is fully rigid against the table/furniture.



- 4 CONNECT AND PLUG IN**
Connect USB cable to to the grommet and the adapter. Lastly, plug the adapter into the a wall socket or power strip.

